



# Digital Thermometer

**INSTRUMENT OPERATION** - The instrument is switched on by pressing any function button located on the front of the thermometer. Apply the tip of the probe to the substance or medium to be measured. The instrument reading may take a few seconds to stabilise, depending on the nature of the measurement. The instrument will automatically turn off after 10 minutes.

**°C/°F** - Press the °C/°F button to select the temperature scale required. The temperature scale chosen will be retained after automatically turning off.

**HOLD** - Press the HOLD button to retain the display reading, press the HOLD button again to resume taking temperature. Please note: once HOLD is selected the unit will not automatically turn off.

**BATTERY REPLACEMENT** - Replace the battery by sliding the battery cover up, replace battery and slide cover down.

**EMC/RFI** - Instrument performance may be affected if operated within a high frequency radio field, such as near a mobile phone, or if subjected to an electrostatic shock.

**GUARANTEE** - This instrument carries a one-year warranty against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of ETI, be either repaired or replaced without charge. This warranty does not apply to probes, where a six-month period is offered. The product warranty does not cover damage caused by fair wear and tear, abnormal storage conditions, incorrect use, accidental misuse, abuse, neglect, misapplication or modification. Full details of liability are available within ETI's Terms & Conditions of Sale at [www.etiltd.com/terms](http://www.etiltd.com/terms). In line with our policy of continuous development, we reserve the right to amend our product specification without prior notice.

## SPECIFICATION

range	-49.9 to 149.9 °C
resolution	0.1 °C or 0.1 °F (switchable)
accuracy	±1 °C
sensor type	thermistor
battery & battery life	1.5 volt button cell LR44 - 5000 hours
display	6 mm LCD
dimensions	20 x 58 x 150 mm
weight	15 grams

*supplied by*

**Electronic Temperature Instruments Ltd**

tel: 01903 202151 · email: [sales@etiltd.com](mailto:sales@etiltd.com)