

## INTRODUCTION

Availability date in Europe: 02/06/2008

## **KEY SELLING POINTS**

- Ideal tool for spot cleaning, cleaning between cleanings and small areas cleaning
- Saves time and money, 50 % faster, more efficient cleaning vs a traditional mop bucket system
- Exceptionally durable and easy to use, unlike other juice-on-board systems

## **KEY MARKET FACTS**

### Eliminating the bucket for improved productivity

About 30% of cleaning jobs are too small to justify mixing an entire bucket with water and chemicals. In addition, in many situations, like on stairs, high traffic areas or small rooms, a bucket is hard to manoeuvre and inefficient.

### Limited efficient competitive offerings

Existing juice-on-board systems are leaking, hard-to-use and inefficient for a daily usage.

## Ergonomics in the workplace

European Cleaning contractors have to ensure the health, safety and wellbeing at the cleaning work of all their employees. They need to use efficient tools that helps reducing RSI (Repetitive Stress Injuries) and MSDs (Musculoskeletal Disorders).

## Prevalence of nosocomial infections in hospitals

Nosocomial Infections have become endemic in many regions where it adds to the morbidity, mortality, and cost of Healthcare. Juice-on-Board system is the ideal solution for spot cleaning (blood spills) in Healthcare. In combination with Ultra-fine Microfibre Mops, it is the most efficient cleaning solution to remove bacteria.



## PRODUCT DESCRIPTION

## Q969 RUBBERMAID PULSE™ MOPPING KIT Includes:

Trigger Handle with Fluid Reservoir and one 40 cm Aluminium Frame

#### TWO REFILLING OPTIONS

LARGE REFILL OPENING Reservoir features a wide refill port for easy manual refilling.



LIGHTWEIGHT CONSTRUCTION

Weighs 1.7 kg only when fully loaded with solution.

CLEAN CONNECT™ CAP In combination with a Pulse™ Caddy Q966 to clean up to 930 m².

Designed to be securely transported in Rubbermaid Cleaning Carts for efficient on-the-go refills.



Q966 - PULSE™ CADDY

#### NON-SLIP TIP

When placed against a wall this tip helps prevent the handle from sliding and falling.



#### TRIGGER HANDLE

Red ergonomic trigger handle dispenses three streams of Cleaning solution with each press. One-handed operation. Helps reducing RSI (Repetitive Stress Injuries).



#### **CLEAN CONNECT™ CAP**

In combination with a Pulse™ Caddy, the user is not exposed to chemicals.



### ON-BOARD FLUID RESERVOIR

High-capacity refillable reservoir holds 0.6L of solution to clean up to 80 m2 of floor space. Reservoir windows allow easy monitoring of fluid level. On-board fluid reservoir considerably improves aesthetics.

Can not be used with Bleach.



#### QUICK-CONNECT SYSTEM

40 cm Aluminium Frame included. Also works with Rubbermaid 28 and 60 cm Aluminium Frames and Mops.



#### **ON-DEMAND DELIVERY**

Press the trigger handles to dispense three streams of cleaning solution behind the mop (non-atomising for greener cleaning).



#### Q471-58 HIGH-ABSORBENCY MOP

The Pulse holds 0.6L of liquid and the High Absorbency Mop will hold up to 0.7L of liquid to clean up to 80 m². They work great together!



## **FEATURES & BENEFITS**

FEATURES	ADVANTAGES	BENEFITS
0.6L Capacity	Clean large area before refilling	Productivity: Clean Faster
Ergonomic Trigger Design	Can be squeezed with 3 fingers	Safety: Less stress on hands
Large fill opening at waist level (instead of at top of handle)	When hand refilling, easier to pour in. Not near user's eyes	Safety: Less likely to spill, get in eyes, or breathe vapors
Full-length fill view windows	Easy to see liquid is in reservoir	Productivity: Refill only when necessary
Three Stream Liquid Dispensing	Spreads liquid evenly behind the mop frame- Non-atomizing	Performance: Consistent cleaning
Pulse™ Caddy fits securely into cleaning cart	Allows user to lock Pulse Caddy inside cart, even when using	Safety: Keeps chemicals away from kids / patients
Clean Connect <sup>™</sup> when refilling Pulse <sup>™</sup> tool with Pulse <sup>™</sup> Caddy	1 Step for hands-free refilling	Safety: No spills from overflowing when refilling, less exposure to vapors
2-years guarantee	Durable	Lower maintenance costs

## FREQUENTLY ASKED QUESTIONS

Q: Do Microfibre Mops come with the Pulse™ system?

A: NO. The Microfibre Mops are sold separately.

Q: What is the most appropriate Mop to use with the Pulse™ system?

A: For smaller jobs, use the standard Q477 Microfibre Wet Mop or the Q470 Microfibre Wet Mop with Scrubber. For larger jobs and areas, use the Q471 High Absorbency Mop.

Q: Can I use the Pulse™ to apply floor finish?

A: NO. The new Flow Finish System is for finish application. Finish will clog the Pulse.



## FREQUENTLY ASKED QUESTIONS

Q: What chemicals can I use in the Pulse?

A: Neutral floor cleaners, quat or phenolic disinfectants, and ceramic tile floor cleaners. Do NOT use Bleach in the Pulse™.

Q: Which Microfibre Mops can I use with the Pulse™?

A: The Pulse<sup>™</sup> comes with a 40 cm frame, so use any 40 cm Microfibre Wet Mop. If you choose to add an 28 cm or 60 cm frame, also use the Microfibre Wet Mops with them as well. 28 cm frame is particularly appropriate for stairs cleaning.

Q: Can I Microfibre Dust Mop with the Pulse™?

A: Absolutely! The Pulse™ is designed to not drip and leak like many competitive units. Therefore, you can use an appropriately sized Microfibre Dust Mops first and then switch to a Microfibre Wet Mop before dispensing liquid.

Q: Will the Pulse™ leak if laid on its side?

A: NO. The Pulse™ will not leak, even if stored upside down.

Q: Does the Pulse™ replace the Q950 Charging Bucket?

A: NO. Some will still prefer using the Charging Bucket system. Each has its advantages. You can actually use the Pulse WITH the Charging Bucket. For instance, when cleaning in Healthcare it is common to clean the vinyl tile floor in the patient room with a neutral cleaner (fill Charging Bucket with Neutral Cleaner) and then clean the tile bathroom with a disinfectant (Fill Pulse™ with Disinfectant).

Q: Is the Pulse™ Caddy included with the Pulse™ Floor Cleaning Kit?

A: NO. The Pulse<sup>™</sup> Caddy with Clean Connect<sup>™</sup> technology is sold separately.

Q: Can I use the Pulse™ Caddy even if I do not have a new Rubbermaid Cleaning Cart?

A: YES. The Pulse™ Caddy has been designed to fit on the shelf of any of our carts.